The Revox C200 Launcher App was developed for the Revox **STUDIO**CONTROL C200 and is pre-installed on the home screen together with the other Revox apps.

Once activated, the Launcher App simplifies the operation of the **STUDIO**CONTROL C200 and puts the important applications in the user's focus.


Advantages

- important apps at one glance

- home screen can be individualized

- simplified operation

- larger app icon representation

- app name well readable

- sortable order

Function Overview

[A]   calls up all installed apps. The desired apps can then be added to the home screen

[B]   swiping left also calls up all installed apps. The desired apps can then be added to the home screen

**[C]**   calls the configuration page of the C200 Launcher App

Set up Standard Launcher

[D]   set the C200 Launcher app as the default launcher for the control.

Open app list


Add app to home screen

Studio Sound Quality

Edit and sort apps

Tap and hold app

← Studioart

Remove from home screen

Reorder Home Apps

App info

Uninstall

Configure Launcher

Revox Launcher

⇄ Change default launcher

Appearance

Show status bar

Show date time

Show battery indicator

Theme mode   **Light**

⚙ System settings

Deactivate C200 Launcher